

Development of Large Area Fast Microchannel Plate Photodetectors


Karen Byrum for the Large Area Picosecond PhotoDetector (LAPPD) Collaboration Argonne National Laboratory

> SPIE Defense, Security and Sensing 2011 Orlando Florida 28 April 2011



Talk Outline

- Introduction and Overview
- MCP Development
- Photocathodes
- Anode and signal readout
- Mechanical Design
- Simulations and TestingConclusion





Introduction: The LAPPD Collaboration

Large Area Picsecond Photodetector Collaboration

John Anderson, Karen Byrum, Gary Drake, Henry Frisch, Edward May, Alexander Paramonov, Mayly Sanchez, Robert Stanek, Robert G. Wagner, Hendrik Weerts, Matthew Wetstein, Zikri Zusof

High Energy Physics Division, Argonne National Laboratory, Argonne, IL

Bernhard Adams, Klaus Attenkofer, Mattieu Chollet

Advanced Photon Source Division, Argonne National Laboratory, Argonne, IL

Zeke Insepov

Mathematics and Computer Sciences Division, Argonne National Laboratory, Argonne, IL

Mane Anil, Jeffrey Elam, Joseph Libera, Qing Peng

Energy Systems Division, Argonne National Laboratory, Argonne, IL

Michael Pellin, Thomas Prolier, Igor Veryovkin, Hau Wang, Alexander Zinovev

Materials Science Division, Argonne National Laboratory, Argonne, IL

Dean Walters

Nuclear Engineering Division, Argonne National Laboratory, Argonne, IL

David Beaulieu, Neal Sullivan, Ken Stenton

Arradiance Inc., Sudbury, MA

Sam Asare, Michael Baumer, Mircea Bogdan, Henry Frisch, Jean-Francois Genat, Herve Grabas, Mary Heintz, Sam Meehan, Richard Northrop, Eric Oberla, Fukun Tang, Matthew Wetstein, Dai Zhongtian

Enrico Fermi Institute, University of Chicago, Chicago, IL

Erik Ramberg, Anatoly Ronzhin, Greg Sellberg

Fermi National Accelerator Laboratory, Batavia, IL

James Kennedy, Kurtis Nishimura, Marc Rosen, Larry Ruckman, Gary Varner

University of Hawaii, Honolulu, HI

Robert Abrams, valentin Ivanov, Thomas Roberts

Muons, Inc., Batavia, IL

Jerry Va'vra

SLAC National Accelerator Laboratory, Menlo Park, CA

Oswald Siegmund, Anton Tremsin

Space Sciences Laboratory, University of California, Berkeley, CA

Dimitri Routkevitch

Synkera Technologies Inc., Longmont, CO

David Forbush, Tianchi Zhao


Department of Physics, University of Washington, Seattle, WA

- Newly funded (end of August 2009) by DOE and NSF
- 4 National Labs
- 5 Divisions at Argonne
- 3 US small companies;
- Electronics expertise at Universities of Chicago and Hawaii
- Photocathode expertise at Washington University, St. Louis and Univ. of Illinois, Chicago

Goals:


- Exploit advances in material science and nanotechnology to develop new, batch methods for producing cheap, large area MCPs.
- Develop path to a commercializable product on a three year time scale (approaching the end of .year 2 – this summer)


Overview: Motivation



Complete particle measurement: E, p + m(PID) 1ps time & 1mm space resolution, \$100k/m²


Time-of-Flight in PET





- Time of flight information reduces noise in images.
- Variance reduction given by 2D/c∆t.
- 500 ps timing resolution
 ⇒ 5x reduction in variance!

• Time of Flight Provides a *Huge* Performance Increase!



Water Cherenkov neutrino detector (DUSEL) ~80-90% coverage and 3-d photon vertex reconstruction 100ps time & 10mm space resolution, \$10k/m²


TOF (Effective Efficiency) Gain for Whole-Body PET (35 cm)

Hardware	∆t (ps)	TOF Gain
BGO Block Detector	3000	0.8
LSO Block (non-TOF)	1400	1.7
LSO Block (TOF)	550	4.2
LaBr ₃ Block	350	6.7
LSO Side Coupled	250	9.3
LSO Small Crystal	210	11.1
Lul ₃ Small Crystal	125	18.7
LaBr ₃ Small Crystal	70	33.3

Incredible Gains Predicted
 Nothing Else Can Give Us Gains of This Size!



Overview: Micro Channel Plates PMTs




Photon and electron paths are short - few mm to microns which results in fast, uniform Planar geometry, scalable to large areas






MCP Development Multichannel Plates






MCP Development: Simplifying MCP Construction



Conventional Pb-glass MCP



Incom Glass Substrate

Chemically produced and treated

- Pb-glass provides 3 functions:
 - Provides pores
 - Resistive layer supplies electric field in the pore
 - Pb-oxide layer provides secondary electron emission

Separate the three functions:

- Hard glass substrate provides pores
- Separate Resistive and Emissive layer functions
- Produce Tuned Resistive Layer (Atomic Layer Deposition, ALD) provides current for electric field;
- Specific Emitting layer provides secondary electron emission



MCP Development: Glass Capillary Substrate Development

Incom


- Glass substrate development, fabrication, finishing by Incom, Inc. (Charlton, MA, USA)
 Borosilicate glass capillary
- Disk development substrates produced in quantity (for R&D)
 - 32.8mm diameter
 - 20µm pore L/D=60
- All substrate pores have 8° bias w.r.t axis ⊥ to substrate
 - Used in pair chevron configuration to reduce positive ion feedback damage to photocathode
- First four 8"×8" 20µm pore substrates delivered Aug 2010






MCP Development: Atomic Layer Deposition

Argonne, Arradiance






J. Elam, A. Mane, Q. Peng, T. Prolier (ANL:ESD/HEP), N. Sullivan (Arradiance), A. Tremsin (Arradiance, SSL)

9

🕖 ENERGY


- A conformal, self-limiting process.
- Allows atomic level thickness control.
- Applicable for a large variety of materials.

Poster by Anil Mane on ALD and LAPPD project: Thur Conf. 8031



borosilicate glass filters







11 U.S. DEPARTMENT OF

3. Apply an emissive coating (ALD)

Conventional MCP's:










12

-

4. Apply a conductive coating to the top and bottom (thermal evaporation or sputtering)








- SEM photos of endspoiling from first use of fixture
- Penetration of electrode into capillary pores is ~30µm




MCP Development: Testing at SSL






MCP Development: Testing at ANL



Photocathodes






Photocathodes: Three thrusts

Argonne, Space Sciences Lab, UC-Berkeley, Washington Univ., St. Louis, Univ. of Illinois, Chicago

- SSL: R&D focus on scaling up of traditional bi-alkalai to large area
 - Proven history with planacon
- ANL/WashU/UICU: R&D focus on theory inspired design
 - New novel photocathode technologies like nanostructured photocathodes
 - III-V have the potential for high QE, shifting toward the blue and robustness (ie. they age well, high temp)
 - Simulations, testing & characterization
- ANL: R&D focus on design for industrial production of large area photocathodes for a tile factory




- Nano-structured photocathodes:
 - Reduction of reflection losses (light trap)
 - Heterogeneous structure permits multi-functionality (electrically, optically, electron-emission, "ionetching resistant")
 - Increased band-gap engineering capabilities




what does this mean for industry

Photocathode Deposition Development


Work performed by Space Sciences Lab, UC-Berkeley







Small tank for 1.22" test run samples Test runs with Fused Silica, Borofloat glass ITO & MgO coated ALD layers on glass; scrubbing Evaporation tooling for 8.7" windows




16" tank for full-sized 8.7" windows






SSL Large Process Chamber







Anode and Signal Development







Anode and Signal Readout


Univ. of Chicago, Univ. of Hawaii • Resolution depends on & photoelectrons, analog bandwidth, and signal-to-noise. Simulations showed "pulse sampling" to give the best results

 \cdot Transmission Line: readout both ends \rightarrow get position and time

- Cover large areas with much reduced channel count.
- Simulations indicate that these transmission lines could be scalable to large detectors without severe degradation of resolution.









Anode and Signal Readout: ASIC Sampling Chip

igger (


•New 10Gs/s high input bandwidth, 130nm CMOS sampling chip is being developed, "PSEC3"

 Proposed schematic of custom transmission line anode & fast sampling ASIC



Chip characteristics	Value
Technology	IBM CMOS 0.13µm
Sampling frequency	>10Gs/s
Number of channel	4
Number of sampling cells	256
Input bandwidth	>2GHz
Dead time	2µs
Number of bits	8
Power consumption	To be measured


Test board for studying PSEC3







Mechanical Design Hermetic Packaging







Mechanical Design: Ceramic

Space Sciences Lab, UC Berkeley

- Use ceramic assemblies, similar to those used by conventional MCPs.
- Well developed technology, know-how available at SSL.







SSL Anode Plates







Mechanical Design: All Glass


Argonne, Univ. of Chicago

Goals:

- Use inexpensive borosilicate glass for containment vessel
- Avoid use of pins penetrating glass for HV and signal
- Cheap, reliable, reproducible containment vessel fab.
- Demonstrate feasibility with partially active mock-up Constraints:
- Support vessel against implosive atmospheric pressure
- Top photocathode window seal at low temp. (<120 ° C)
- ~10 yr stability for seal with small leak rate
- Min. handling steps in fabrication
- Avoid particulates in vacuum space
- Materials chemicall compatible with alkali metal photocathode



Our first sealed box under pressure. It is a 8" square sealed box










Tile Base Assembly -- Anode Bottom Plate & Sidewall



Sidewall bonds on alternating silver strips and bare glass gaps. Extension of strip past sidewall for bridging between tiles & readout connection.

- Develop technique to reproducibly bond sidewall to bottom anode plate
 - Center sidewall frame w.r.t. bottom plate; 2 sides flush, equal overhang
 - on anode ground strips
 - Attach getter holder tubes




Original steel fritting fixture replaced with much simpler all glass devised by Joe Gregar




Construction of first all glass mock tile:






a) 2.97mm bottom Grid Spacer b) add Mock MCP






c) add functionalized MCPs

d) add 1.1mm Grid spacer




e) Add mock MCPs, 33mm functionalized MCPs & top 1.1mm Grid spacer



f) full stack in mock tile



g) Anil & Bob Holding mock tile



h) Mock tile after sealing & evacuation



Simulations and Testing

Microscopic/Materials-Level

Material Science Division, ANL

Constructing dedicated setup for lowenergy SEE and PE measurements of ALD materials/photocathodes.

parts-per-trillion capability for characterizing material composition.

Macroscopic/Device-Level

HEP Laser Test Stand, ANL

Fast, low-power laser, with fast scope.

Built to characterize sealed tube detectors, and front-end electronics.

Highly Automated

Berkeley SSL

Decades of experience.

Wide array of equipment for testing individual and pairs of channel plates.

Infrastructure to produce and characterize a variety of conventional photocathodes.

Advanced Photon Source, ANL


Fast femto-second laser, variety of optical resources, and fast-electronics expertise.

Study MCP-photocathode-stripline systems close to device-level. Timing characteristics amplification etc.




Simulations

- Working to develop a firstprinciples model to predict MCP behavior, at device-level, based on microscopic parameters.
- Will use these models to understand and optimize our MCP designs.



Transit Time Spread (TTS)

TTS






Conclusion

- Large Area Picosecond Photodetector Development collaboration is on track to deliver a working prototype by the end of year 3 (summer 2012)
- Atomic Layer Deposition coatings of 33mm glass capillary disks are producing gain >10⁶ for MCP pair; Are in the process of scaling up to 8" ALD
- Have developed 3 ALD resistive + 2 ALD emissive chemistries
- Mature mechanical designs for hermetically sealed tube
 - Proven design in ceramic by SSL
 - Well-advanced inexpensive glass design -- first hermetic box completed
- Moving to reliable and reproducible fabrication of sealed tubes in quantity
- Designing a tile production facility at Argonne
 - Lab space for tile facility is being developed
 - Layout design of labs for wet chemistry and vacuum handling underway





Anode and Signal Readout: First Mock Tile





Backup



MCP Development: Electrode Evaporation onto MCPs - Endspoiling

Fermilab and Space Sciences Laboratory, Berkeley, UC


- Metallization for electrical contact applied to bare glass capillary before ALD
- Nichrome evaporation performed at Fermilab Thin Film Facility and as SSL
- FNAL Fixture must rotate MCP about 8° bias of pores
- Penetration of electrode into pores is 1 diameter, i.e. 20µm (endspoiling)

SSL current Bell jar setup for fixturing 33mm sample evaporations and cartoon of modifications to accommodate 8" tiles

FNAL












MCP Development: Scale-up of ALD Processing


- Studying ALD on Large Surface Areas
- 33mm disk surface area is 0.13m²
- 8" x 8" surface area is
 6.4m²
- 20 MCPs area is 129m²





New Beneg Reactor










New Photocathode Lab at Argonne w/Burle Equipment








New Burle Equip.

- Just sitting up equipment
- First photocathodes w/QE>15%
- Plan to use this eqpt for mock tile assembly scaleup

Photocathode Lab Plan View



U.S. DEPARTMENT OF ENERGY

22

Holes for LED light

